

Product Specification



DRIVESAFE EXEC Breath Alcohol



PRODUCT OVERVIEW

The DRIVESAFE EXEC Breath Alcohol provides accurate results within seconds, using the latest electrochemical sensor technology – the same advanced technology that is standard for law enforcement portable breath testers.

The device offers a single point of reference for unbiased evaluations of breath alcohol concentration.

Breath alcohol test measurements are shown on a 3-digit LCD screen, along with a graphical intensity meter and a tricolour backlight, providing clear results.

SPECIFICATIONS

Size	137mm x 59mm x 26mm
Weight	155 grams
Sensor	Electrochemical (fuel cell)
Specificity	Alcohol only, no response to ketones or hydrocarbon
Temperature Range	0 to 50 °C
Initial Test	<10 seconds
Breath Sample	5 seconds moderate and continuous breath sample
Analysis Time	<10 seconds
Recycle Time	20 seconds
Readout Format	BAC (g/dL, g/L); BrAC (mg/L, µg/L, µg/dL)
Range of Measurement	0.00 to 0.75 mg/L (150 mg/dL, 0.15 g/dL)
Accuracy	± 5% @ 0.50 mg/L (100 mg/dL, 0.10 g/L)
Display	3 digit LCD with graph and tri-colour backlight
Battery	2 AA batteries
Battery Life	1000 tests
Mouthpiece	Disposable (95-000250)
Calibration	ALCOSIM™ or equivalent

FOR MORE INFORMATION, CONTACT OUR SALES TEAM.

T: 020 8863 8333 (OPT1) • **E:** sales@c-ko.co.uk • **W:** www.c-ko.co.uk

Product Specification



DRIVESAFE EXEC Breath Alcohol

Ease of Use

Icons on the LCD screen guide the operator confidently through the test sequence and indicate any errors or missteps made during the process. All functions are easily controlled using a single button.

Simple Process

The device automatically indicates when to take the test. Simply insert a fresh mouthpiece into the device and provide a breath sample. A tone sounds to indicate proper breath flow, and a beep sounds after 5 seconds of continuous flow to indicate that an appropriate sample has been received.

The result of the analysis appears within a few seconds on an easy to read LCD screen.

Credible Performance

Advanced alcohol-specific electrochemical sensors offer long-term stability, for accurate results over years of use. Calibration is maintained with breath alcohol simulators and alcohol reference solution. Please note that any further maintenance should only be performed by qualified technicians.

Ready For Use

Each tester comes fully equipped with 2x AA alkaline batteries, operating instructions, a protective carry case, and five mouthpieces.



FOR MORE INFORMATION, CONTACT OUR SALES TEAM.

T: 020 8863 8333 (OPT1) • **E:** sales@c-ko.co.uk • **W:** www.c-ko.co.uk